

To improve supply and make ordering easier Amal have introduced a range of ACK and PACK part numbers which package carburetters together to suit particular bikes. ACK indicates standard carburetters and PACK is used for Premiers. The kit numbers and the bikes they are for are listed below.

Standard MK1 Carburetter Kits				
Application	Specification No's in the Kit			ACK number
MK 1 Concentric 28mm 4 Stroke Base set	928/300	928/301		ACK 100
MK 1 Concentric 30mm 4 Stroke Base set	930/300	930/301		ACK 101
MK 1 Concentric 32mm 4 Stroke Base set	932/300	932/301		ACK 102
MK 1 Concentric 26mm 4 Stroke Base set	626/300	626/301		ACK 103
AJS Model 33CSR 1967-69	930/5	930/6		ACK 110
BSA A65 Lightning 1971-72	930/70	930/71		ACK 120
BSA A65FS, A65SS 1971	930/72	930/73		ACK 119
BSA A65L, A65FS, A65SS 1968	930/21	930/22		ACK 118
BSA A65L, A65FS, A65SS 1969-70	930/34	930/35		ACK 117
BSA A70 Lightning USA 750cc	930/78	930/79		ACK 121
BSA Spitfire MKIII 1968	932/1	932/2		ACK 116
Ducati 750 GT 1971-74	930/76	930/77		ACK 129
Moto Guzzi 750 Twin 1972-74	930/80	930/81		ACK 131
Norton Atlas 1967-68	930/7	930/8		ACK 109
Norton Combat 750cc 1972	932/19	932/20		ACK 140
Norton Combat 750cc 1973	932/26	932/27		ACK 112
Norton Commando 750cc 1968	930/26	930/27		ACK 133
Norton Commando 750cc 1968-72	930/68	930/69		ACK 111
Norton Commando 750cc 1969	930/30	930/31		ACK 134
Norton Commando 750cc 1970	930/46	930/47		ACK 135
Norton Commando 750cc 1973	930/82	930/83		ACK 139
Norton Commando 850cc 1974	932/33	932/34		ACK 113
Norton Commando MK1 850cc 1973-74	932/29	932/30		ACK 136
Norton Commando MK1A 850cc 1973-74	932/31	932/32		ACK 137
Norton Commando MK2 850cc 1974	932/35	932/36		ACK 138
Norton Dominator 650SS 1967-68	930/17	930/18		ACK 115
Norton Model 99 1967-68	930/19	930/20		ACK 132
Norton Roadster MKIII 1974	932/42	932/43		ACK 114
Royal Enfield Interceptor 1969-70	930/32	930/33		ACK 122
Royal Enfield Interceptor Series 1 & 2 1967-68	930/3	930/4		ACK 141
Triumph T100/T100C 1968-69	626/9	626/10		ACK 106
Triumph T100/T100R 1970-72	626/53	626/54		ACK 107
Triumph T100SS Daytona 1973-74	626/64	626/65		ACK 144
Triumph T100T Daytona 1970	626/26	626/27		ACK 143
Triumph T120 1969-70	930/9	930/10		ACK 104
Triumph T120 1970	930/43	930/44		ACK 145
Triumph T120 1971-73	930/66	930/67		ACK 126
Triumph T120R & T120V 1973	930/84	930/85		ACK 146
Triumph T140 1973-78	930/92	930/93		ACK 105
Triumph T140V 1973	930/87	930/88		ACK 147
Triumph T150 1969-70	626/14	626/15	626/16	ACK 123
Triumph T150 Hurricane 1973	626/69	626/70	626/71	ACK 128
Triumph T150R Trident 1971	626/47	626/48	626/49	ACK 148
Triumph T150R Trident 1971-74	626/66	626/67	626/68	ACK 124
Triumph T160 Trident 1975	626/72A	626/73A	626/72A	ACK 149
Triumph T160 Trident 1975-76	626/76	626/77	626/76	ACK 125

Premier MK1 Carburetter Kits

Application	Specification No's in the Kit			PACK Number
MK 1 Concentric 28mm 4 Stroke Base set	928/300PREM	928/301PREM		PACK 100
MK 1 Concentric 30mm 4 Stroke Base set	930/300PREM	930/301PREM		PACK 101
MK 1 Concentric 32mm 4 Stroke Base set	932/300PREM	932/301PREM		PACK 102
MK 1 Concentric 26mm 4 Stroke Base set	626/300PREM	626/301PREM		PACK 103
AJS Model 33CSR 1967-69	930/5PREM	930/6PREM		PACK 110
BSA A65 Lightning 1971-72	930/70PREM	930/71PREM		PACK 120
BSA A65FS, A65SS 1971	930/72PREM	930/73PREM		PACK 119
BSA A65L, A65FS, A65SS 1968	930/21PREM	930/22PREM		PACK 118
BSA A65L, A65FS, A65SS 1969-70	930/34PREM	930/35PREM		PACK 117
BSA A70 Lightning USA 750cc	930/78PREM	930/79PREM		PACK 121
BSA Spitfire MKIII 1968	932/1PREM	932/2PREM		PACK 116
Ducati 750 GT 1971-74	930/76PREM	930/77PREM		PACK 129
Moto Guzzi 750 Twin 1972-74	930/80PREM	930/81PREM		PACK 131
Norton Atlas 1967-68	930/7PREM	930/8PREM		PACK 109
Norton Combat 750cc 1972	932/19PREM	932/20PREM		PACK 140
Norton Combat 750cc 1973	932/26PREM	932/27PREM		PACK 112
Norton Commando 750cc 1968	930/26PREM	930/27PREM		PACK 133
Norton Commando 750cc 1968-72	930/68PREM	930/69PREM		PACK 111
Norton Commando 750cc 1969	930/30PREM	930/31PREM		PACK 134
Norton Commando 750cc 1970	930/46PREM	930/47PREM		PACK 135
Norton Commando 750cc 1973	930/82PREM	930/83PREM		PACK 139
Norton Commando 850cc 1974	932/33PREM	932/34PREM		PACK 113
Norton Commando MK1 850cc 1973-74	932/29PREM	932/30PREM		PACK 136
Norton Commando MK1A 850cc 1973-74	932/31PREM	932/32PREM		PACK 137
Norton Commando MK2 850cc 1974	932/35PREM	932/36PREM		PACK 138
Norton Dominator 650SS 1967-68	930/17PREM	930/18PREM		PACK 115
Norton Model 99 1967-68	930/19PREM	930/20PREM		PACK 132
Norton Roadster MKIII 1974	932/42PREM	932/43PREM		PACK 114
Royal Enfield Interceptor 1969-70	930/32PREM	930/3PREM		PACK 122
Royal Enfield Interceptor Series 1 & 2 1967-68	930/3PREM	930/4PREM		PACK 141
Triumph T100/T100C 1968-69	626/9PREM	626/10PREM		PACK 106
Triumph T100/T100R 1970-72	626/53PREM	626/54PREM		PACK 107
Triumph T100SS Daytona 1973-74	626/64PREM	626/65PREM		PACK 144
Triumph T100T Daytona 1970	626/26PREM	626/27PREM		PACK 143
Triumph T120 1969-70	930/9PREM	930/10PREM		PACK 104
Triumph T120 1970	930/43PREM	930/44PREM		PACK 145
Triumph T120 1971-73	930/66PREM	930/67PREM		PACK 126
Triumph T120R & T120V 1973	930/84PREM	930/85PREM		PACK 146
Triumph T140 1973-78	930/92PREM	930/93PREM		PACK 105
Triumph T140V 1973	930/87PREM	930/88PREM		PACK 147
Triumph T150 1969-70	626/14PREM	626/15PREM	626/16PREM	PACK 123
Triumph T150 Hurricane 1973	626/69PREM	626/70PREM	626/71PREM	PACK 128
Triumph T150R Trident 1971	626/47PREM	626/48PREM	626/49PREM	PACK 148
Triumph T150R Trident 1971-74	626/66PREM	626/67PREM	626/68PREM	PACK 124
Triumph T160 Trident 1975	626/72PREM	626/73PREM	626/72PREM	PACK 149
Triumph T160 Trident 1975-76	626/76PREM	626/77PREM	626/76PREM	PACK 125

MK1 1/2 & MK2 Carburetter Kits

Application	Specification No's in the Kit			ACK number
MKII Concentric 30mm 4 Stroke Base set	2930/300	2930/301		ACK 205
Triumph Harris Bonneville 1985-87	930/111	930/112		ACK 200
Triumph T140D & T140E 1979-83	2930/1	2930/2		ACK 201
Triumph T140D & T140E 1981-83	2930/8	2930/9		ACK 202
Triumph TSS & TS8 1982	2934/7	2934/8		ACK 203

Monobloc Carburetter Kits

Application	Specification No's in the Kit			ACK number
AJS Model 30 1957-59	376/95	376/96		ACK 300
AJS 31CSR & Matchless G12CSR 1962-65	389/73	389/74		ACK 301
AJS 33CSR & Matchless G15CSR 1965	389/222	389/223		ACK 302
AJS Model 33 & Matchless G15 1964-65	389/87	389/88		ACK 303
BSA A65L Lightning Rocket 1964-65	389/206	389/206		ACK 304
Excelsior 3 Cyl Berkeley 1957-60	376/200	376/200	376/200	ACK 307
Excelsior Berkeley Twin 1957-58	376/93	376/93		ACK 306
Excelsior Super Tailsman Twin 1958	376/94	376/94		ACK 308
Greeves ME Starmaker 1963	389/89	389/90		ACK 309
Matchless G15CS & Norton N15CS 1964	389/210	389/211		ACK 310
Norton Atlas 1965	389/218	389/219		ACK 317
Norton Dominator 650SS 1965-66	376/317	376/318		ACK 314
Norton Dominator Model 88 1959-60	376/219	376/219		ACK 311
Norton Dominator Sports 1963-64	376/288	376/289		ACK 313
Norton Model 77 1960-61 & Model 99 Sports 1962	376/220	376/220		ACK 316
Norton Model 88 & Deluxe 1960-62	376/247	376/247		ACK 312
Norton Model 99 USA 1965-66	376/274	376/275		ACK 315
Royal Enfield Constellation 1959-61	376/242	376/243		ACK 322
Royal Enfield Constellation 1960-61	389/55	389/56		ACK 323
Royal Enfield Interceptor 1963	389/85	389/86		ACK 324
Speedwell 1959	389/43	389/44		ACK 325
Speedwell 1959	376/266	376/267		ACK 326
Speedwell 1959-60	376/236	376/237		ACK 327
Triumph Bonneville T120 & T120C 1960-63	376/257	376/257		ACK 332
Triumph Bonneville T120 1959	376/204	376/204		ACK 329
Triumph Bonneville T120 1959	376/233	376/233		ACK 330
Triumph Bonneville T120 1962-63	376/286	376/287		ACK 333
Triumph Bonneville T120, TR7A & TR7B 1960	389/51	389/51		ACK 331
Triumph T100T & T100R Daytona 1967	376/324	376/325		ACK 328
Triumph T120C, T120RS (Johnson Motors) 1963-67	389/95	389/95		ACK 334
Triumph T120R Johnson Motors 1963	376/302	376/302		ACK 336
Triumph T120R USA 1966	389/203	389/203		ACK 335
Villiers StarMaker 1962-63	389/89	389/90		ACK 337
Vincent Black Prince & Black Shadow 1955	389/10	389/10		ACK 338

Pre-Monobloc Carburetter Kits

Application	Specification No's in the Kit		ACK number
AJS 20 Twin 1953	76AQ	76AP	ACK 400
Douglas 80 Plus 1951-54	276EQ/1B	276EP/1B	ACK 401
Douglas 90 Plus 1947-54	276EN/2DX	276EM/2DX	ACK 402
Norton N15 Nomad Twin 1959	276GX/1AT	276GY/1DA	ACK 403
Norton N15 Nomad Twin 1959-60	276GV/1DA	276GW/1AT	ACK 404
Puch Model SG/SS 1958-59	289AA/2EP	289AB	ACK 405
Triumph T100 Racing 1949-50	76AJ	76AH	ACK 406
Triumph T100C 1953	76AS	76AR	ACK 408
Triumph T100R 1951-52	76AO	76AN	ACK 407
Vincent B Rapide 1946-49	276CJ/1DO	276CH/2DS	ACK 409
Vincent Black Shadow 1947-48	289M/1DO	289N/2DS	ACK 411
Vincent Black Shadow 1949-54	229E/1DV	289N/2DS	ACK 412
Vincent C Rapide 1949-54	276DQ/1DV	276CH/2DS	ACK 410